



中航太克  
All For Reliability

# 智能在线式 UPS

# 通讯协议

[www.avic-tech.com.cn](http://www.avic-tech.com.cn)

中航太克（厦门）电力技术股份有限公司

Case Name:		Date:		Num:	
Case Num:		Version:		PAGE	2/32

Modify Note

Num	Version	Modify content	Author	Date	Confirm	Date
0	00	First draft	zhupei	2016-1-22		
1	01	Modify	Horace	2020-4-24		

TOBTAK 中航大

Case Name:		Date:		Num:	
Case Num:		Version:		PAGE	3/32

# CATALOGUE

<b>1</b>	<b>DOCUMENT DESCRIPTION.....</b>	<b>7</b>
1.1	GOALS.....	7
1.2	ORGANIZATION.....	7
1.3	REFERENCE DOCUMENT.....	7
1.4	GLOSSARY – ABBREVIATIONS – NOTATIONS.....	7
<b>2</b>	<b>CRC DESCRIPTION.....</b>	<b>7</b>
<b>3</b>	<b>HARDWARE DESCRIPTION.....</b>	<b>9</b>
<b>4</b>	<b>UPS RESPOND DESCRIPTION.....</b>	<b>9</b>
<b>5</b>	<b>INQUIRY COMMAND.....</b>	<b>10</b>
5.1	^P005Q3GS<0x0D>: THE GENERAL STATUS PARAMETERS INQUIRY.....	10
5.2	^P005Q3LD<0x0D>: THE LOAD INFORMATION INQUIRY.....	11
5.3	^P004Q3Y<0x0D>: THE BYPASS INFORMATION INQUIRY.....	11
5.4	^P005QBRT<0x0D>: THE BATTERY FIXED PARAMATER INQUIRY.....	12
5.5	^P005QBTT<0x0D>: SHUT DOWN TIME INQUIRY.....	12
5.6	^P004QBV<0x0D>: BATTERY VOLTAGE PARAMATER INQUIRY.....	12
5.7	^P005QFLG<0x0D>: SETTING FLAG STATUS INQUIRY.....	12
5.8	^P004QFS<0x0D>: THE LAST FAULT CODE INQUIRY.....	14
5.9	^P004QID<0x0D>: UPS SERIAL NUMBER INQUIRY.....	17
5.10	^P004QMD<0x0D>: UPS MODE INQUIRY.....	17
5.11	^P004QPI<0x0D>: PROTOCOL ID INQUIRY.....	17
5.12	^P005QRHL<0x0D> : UPS RANGE INQUIRY.....	17
5.13	^P004QRI<0x0D>: UPS RATING INFORMATION INQUIRY.....	18
5.14	^P005QTPR<0x0D>: THE TEMPERATURE INQUIRY.....	18
5.15	^P005QVFW<0x0D>::DSP AND CPU FIRMWARE VERSION INQUIRY.....	18

Case Name:		Date:		Num:	
Case Num:		Version:		PAGE	4/32
5.16	^P004QWS<0x0D>: WARNING STATUS INQUIRY.....				19
5.17	^P006QTYPE<0x0D>:INPUT TYPE INQUIRY.....				22
<b>6</b>	<b>SET COMMAND.....</b>				<b>22</b>
6.1	^S005BOFF<0x0D>: SILENCE BUZZER BEEP.....				22
6.2	^S004BON<0x0D>: BUZZER BEEP OPEN.....				22
6.3	^S005CFTD<0x0D>: DEFAULT CALIBRATION FACTOR.....				22
6.4	^S009CHMC04.0<0x0D>: SET CHARGING CURRENT.....				23
6.5	^S003CS<0x0D>:CANCEL SHUTDOWN AND RESTORE.....				23
6.6	^S003CT<0x0D>: CANCEL BATTERY TEST.....				23
6.7	^S009PHFH52.0<0x0D>:SET ECO FREQ HIGH LOSS POINT.....				23
6.8	^S009PHFL48.0<0x0D>:SET ECO FREQ LOW LOSS POINT.....				23
6.9	^S008PHVH240<0x0D>:SET ECO VOLTAGE HIGH LOSS.....				24
6.10	^S008PHVL200<0x0D>:SETECO VOLTAGE LOW LOSS.....				24
6.11	^S005PFTD<0x0D>:DEFAULT PARAMETER FACTOR.....				24
6.12	^S009PSFH52.0<0x0D>:SET BYPASS FREQ HIGH LOSS POINT.....				24
6.13	^S009PSFL48.0<0x0D>:SET BYPASS FREQ LOW LOSS POINT.....				24
6.14	^S010PSVH240.0<0x0D>:SET BYPASS VOLTAGE HIGH LOSS POINT.....				25
6.15	^S010PSVL200.0<0x0D>:SET BYPASS VOLTAGE LOW LOSS POINT.....				25
6.16	^S005REEP<0x0D>:RESTORE EEPROM DATE.....				25
6.17	^S009SBHV15.0<0x0D>:SET THE BATTERY HIGH WARNING VOLTAGE.....				25
6.18	^S009SBLV11.4<0x0D>:SET THE BATTERY LOW WARNING VOLTAGE.....				25
6.19	^S009SBSV10.5<0x0D>:SET THE BATTERY UNDER(SHUTDOWN) VOLTAGE.....				26
6.20	^S008SOPV220<0x0D>:SET OUTPUT VOLTAGE.....				26
6.21	^S005SN.6<0x0D>:SET SHUT DOWN TIME IN NN MINUTE.....				26
6.22	^S005SOFF<0x0D>:TURN OFF THE UPS.....				26
6.23	^S004SON<0x0D>:TURN ON THE UPS.....				26

Case Name:		Date:		Num:	
Case Num:		Version:		PAGE	5/32
6.24	^S009SOPF60.0<0x0D>:SET THE OUTPUT FREQUENCY.....				26
6.25	^S005SPDA<0x0D>:DISABLE CONTROL FLAG.....				27
6.26	^S005SPEA<0x0D>:ENABLE CONTROL FLAG.....				27
6.27	^S007SR0010<0x0D>:RESTART IN NNNN MINUTE.....				27
6.28	^S022STID0123456789ABCDEDEF<0x0D>:SET UPS SERIAL NUMBER.....				28
6.29	^S004T10<0x0D>:DO BATTERY TEST FOR 10 SECOND.....				28
6.30	^S003TL<0x0D>:DO BATTERY TEST UNTIL BATTERY LOW.....				28
6.31	^S005TN.8<0x0D>:DO BATTERY TEST FOR NN MINUTE.....				28
6.32	^S009SINTYPE<N><0x0D>:SET INPUT TYPE LINE OR GENERATOR.....				28
<b>7</b>	<b>CALIBRATION COMMAND.....</b>				<b>29</b>
7.1	^C008RLV+007<0x0D>: CALIBRATION R LINE VOLTAGE.....				29
7.2	^C008SLV+007<0x0D>: CALIBRATION S LINE VOLTAGE.....				29
7.3	^C008TLV+007<0x0D>: CALIBRATION T LINE VOLTAGE.....				29
7.4	^C008ROV+007<0x0D>: CALIBRATION R OUTPUT VOLTAGE.....				29
7.5	^C008SOV+007<0x0D>: CALIBRATION S OUTPUT VOLTAGE.....				29
7.6	^C008TOV+007<0x0D>: CALIBRATION T OUTPUT VOLTAGE.....				30
7.7	^C008ROC+007<0x0D>: CALIBRATION R OUTPUT CURRENT.....				30
7.8	^C008SOC+007<0x0D>: CALIBRATION S OUTPUT CURRENT.....				30
7.9	^C008TOC+007<0x0D>: CALIBRATION T OUTPUT CURRENT.....				30
7.10	^C009RIVV+007<0x0D>:CALIBRATION R INVERTER VOLTAGE.....				30
7.11	^C009SIVV+007<0x0D>:CALIBRATION S INVERTER VOLTAGE.....				30
7.12	^C009TIVV+007<0x0D>:CALIBRATION T INVERTER VOLTAGE.....				31
7.13	^C009RBYV+007<0x0D>: CALIBRATION R BYPASS VOLTAGE.....				31
7.14	^C009SBYV+007<0x0D>: CALIBRATION S BYPASS VOLTAGE.....				31
7.15	^C009TBYV+007<0x0D>: CALIBRATION T BYPASS VOLTAGE.....				31
7.16	^C010BUSPV+007<0x0D>:CALIBRATION POSITIVE BUS VOLTAGE.....				31

Case Name:		Date:		Num:	
Case Num:		Version:		PAGE	6/32

7.17	^C010BUSNV+007<0x0D>:CALIBRATION NEGATIVE BUS VOLTAGE.....	32
7.18	^C010BATPV+007<0x0D>:CALIBRATION POSITIVE BATTERY VOLTAGE.....	32
7.19	^C010BATNV+007<0x0D>:CALIBRATION NEGATIVE BATTERY VOLTAGE.....	32

TOBTAK 中航大瓦

Case Name:		Date:		Num:	
Case Num:		Version:		PAGE	7/32

## 1 Document Description

### 1.1 Goals

This document specifies the RS232 communication protocol used in the Galleon II UPS.

### 1.2 Organization

There are three parts in this manual:

1. Introducing the Inquiry Command. By sending the commands you can get the information of the UPS you need. In the part some signals and their inquiry command are listed too.
2. Introducing the setting Command. By sending the control commands you can control the UPS.
3. Introducing the calibration Command. By sending the calibration Command you can calibration some parameter of the UPS.
4. Computer will control information exchange by a query followed by <cr>.
5. Computer and UPS respond both the "<cr>" as the end of a response.
6. UPS respond with "^" start, and with ";" separate the data.
7. In a UPS's response, if there is no data, with "-" instead of data, and the length of the "-" as long as data.
8. In a UPS's response, if some data length is less than the definition, type enough "#" before the data.

### 1.3 Reference document

None

### 1.4 Glossary – Abbreviations – Notations

None

## 2 CRC Description

The CRC in this document is a general standard of CRC-16 and is generated by the Half Byte look-up table method.

The Table is as follows:

```
crc_ta = {
0x0000,0x1021,0x2042,0x3063,0x4084,0x50a5,0x60c6,0x70e7,
0x8108,0x9129,0xa14a,0xb16b,0xc18c,0xd1ad,0xe1ce,0xf1ef
```

Case Name:		Date:		Num:	
Case Num:		Version:		PAGE	8/32

```
}

```

The CRC generate method is show as below:

```
INT16U cal_crc_half(INT8U *pin, INT8U len)

```

```
{

```

```
    INT16U crc;

```

```
    INT8U da;

```

```
    INT8U *ptr;

```

```
    INT8U bCRCHign;

```

```
    INT8U bCRCLow;

```

```
    ptr=pin;

```

```
    crc=0;

```

```
    while(len--!=0) .....1

```

```
    {

```

```
        da=((INT8U)(crc>>8))>>4;

```

```
        crc<<=4;

```

```
        crc^=crc_ta[da^((( *ptr)&0xFF)>>4)]; .....2

```

```
        da=((INT8U)(crc>>8))>>4;

```

```
        crc<<=4;

```

```
        crc^=crc_ta[da^(*ptr&0x0f)];

```

```
        ptr++;

```

```
    }

```

```
    bCRCLow = (INT8U)(crc & 0x00FF);

```

```
    bCRCHign= (INT8U)(crc>>8);

```

```
    if(bCRCLow==0x28 || bCRCLow==0x0d || bCRCLow==0x0a)

```

```
    {

```

```
        bCRCLow++;

```

```
    }

```

```
    if(bCRCHign==0x28 || bCRCHign==0x0d || bCRCHign==0x0a)

```

```
    {

```

```
        bCRCHign++;

```

```
    }

```

```
    crc = ((INT16U)bCRCHign)<<8;

```



Case Name:		Date:		Num:	
Case Num:		Version:		PAGE	9/32

```

crc += bCRCLow;
return(crc);
}

```

For example:

UPS respond as follows data ^D007PI35<CRCH><CRCL><0x0d>

1,len means the length of data form ‘^’ to ‘5’,equal to 9;

2,\*ptr means get the data from the first responding data address, this is ‘^’.

When calculate the crc ,<CRCH> equal to (crc >>8 )&0xFF, means the high byte of CRC;

<CRCL> equal to crc&0xFF, means the low byte of CRC.

### 3 Hardware Description

BAUD RATE.....: 2400 bps

DATA LENGTH.....: 8 bits

STOP BIT.....: 1 bit

PARITY.....: NONE

Cabling:

COMPUTER		UPS
RX (pin2)	<----->	TX
TX (pin3)	<----->	RX
GND (pin5)	<----->	GND
(9 pins female D-type connector)		

### 4 UPS Respond Description

The UPS responding contents are as follows:

^DNNNAA,BBB.B,CCC.C,DDD.D.....<CRCH><CRCL><cr>

“^D” is a fixed form.

“NNN” means the length of the responding data (from the byte after NNN to byte <cr>).

“AA,BBB.B,CCC.C,DDD.D.....”:means responding data(refer to 5~7 chapter).

<CRCH>:means the high byte of CRC.

<CRCL>:means the low byte of CRC.

<cr>:means the end of a response.(This document also writes as <0x0d>)

Case Name:		Date:		Num:	
Case Num:		Version:		PAGE	10/32

## 5 Inquiry Command

### 5.1 ^P005Q3GS<0x0d>: The general status parameters inquiry

Computer: ^P005Q3GS<0x0d>

UPS:^D113AA,BBB.B,CCC.C,DDD.D,EE.E,FFF.F,GGG.G,HHH.H,II.I,JJJ.J,KKK.K,LLL.L,  
MMM.M,NNN.N,OOO.O,PPP.P,QQQ.Q,RRR.R,SSS,b9b8b7b6b5b4b3b2b1b0a0<CRC  
H><CRC L><0x0d>

AA	UPS Work mode
BBB.B	Line Voltage R
CCC.C	Line Voltage S
DDD.D	Line Voltage T
EE.E	Line frequency
FFF.F	Output Voltage R
GGG.G	Output Voltage S
HHH.H	Output Voltage T
II.I	Output Frequency
JJJ.J	Output Current R
KKK.K	Output Current S
LLL.L	Output Current T
MMM.M	Load Percent R
NNN.N	Load Percent S
OOO.O	Load Percent T
PPP.P	Total Load Percent
QQQ.Q	Battery voltage P
RRR.R	Battery voltage N
SSS	Max temperature
	Ups type 00: standby
b9b8	01: line-interactive
	10: on-line
b7	Utility Fail
b6	Battery Low
b5	Bypass mode
b4	UPS Failed
b3	EPO active
b2	Test in Progress
b1	Shutdown Active
b0	mute status (bat silence)
a0	battery test ok

Case Name:		Date:		Num:	
Case Num:		Version:		PAGE	11/32

## 5.2 ^P005Q3LD<0x0d>: The Load Information Inquiry

Computer: ^P005Q3LD<0x0d>

UPS: ^D0109AAA.A, BBB.B, CCC.C, DDD.D, EEE.E, FFF.F, GGG.G, HHH.H, III.I, JJJ.J, KKK.K, LLL.L, MMMM, NNNNN, OOOOO, PPPPP, QQQQQ, RRRRR <CRCH><CRCL><0x0d>

AAA. A	Max Load Percent R
BBB. B	Max Load Percent S
CCC. C	Max Load Percent T
DDD. D	Max Total Percent
EEE. E	Load VA Percent R
FFF. F	Load VA Percent S
GGG. G	Load VA Percent T
HHH. H	Load VA Total Percent
III. I	Load Watt Percent R
JJJ. J	Load Watt Percent S
KKK. K	Load Watt Percent T
LLL. L	Load Watt Total Percent
MMMM	Load VA R
NNNN	Load VA S
OOOO	Load VA T
PPPP	Load Watt R
QQQQ	Load Watt S
RRRR	Load Watt T

## 5.3 ^P004Q3Y<0x0d>: The Bypass Information Inquiry

Computer: ^P004Q3Y<0x0d>

UPS: ^D043AAA.A, BBB.B, CCC.C, DDD.D, EEE.E, FFF.F, GG.G <CRC H><CRC L><0x0d>

AAA. A	Bypass Voltage R
BBB. B	Bypass Voltage S
CCC. C	Bypass Voltage T
DDD. D	Bypass Current R
EEE. E	Bypass Current S
FFF. F	Bypass Current T
GG. G	Bypass Frequency

Case Name:		Date:		Num:	
Case Num:		Version:		PAGE	12/32

#### 5.4 ^P005QBRT<0x0d>: The battery fixed paramater inquiry

Computer: ^P005QBRT<0x0d>

UPS: ^D033AA.A,BB.B,CCC,DDD.D,EE.E,FF.F,GG,HHH<CRC H><CRC L><0x0d>

Item	Description	Range
AA. A	Reserved	120
BB. B	Battery shutdown voltage	10. 5V~12. 0V
CC. C	Battery Low voltage	(shutdown+0. 1V)~(shutdown+2V)
DDD	Reserved	0
EEE. E	Reserved	4. 0
FF. F	Battery High voltage	14. 0~15. 0
GG	battery cell number	16~20/8~10
HHH	Reserved	0

#### 5.5 ^P005QBTT<0x0d>: Shut down time inquiry

Computer: ^P005QBTT<0x0d>

UPS: ^D011AAA,CC.C<CRC H><CRC L><0x0d>

AAA	Shut down time (second)
CC. C	Shut down time (minute)

#### 5.6 ^P004QBV<0x0d>: battery voltage paramater inquiry

Computer: ^P004QBV<0x0d>

UPS: ^D049AAA.A,BBB.B,CCCC.C,DDD.D,EEE.E,FFFF.F,GGG,HHHH<CRC.H><CRC L><0x0d>

AAA. A	Battery Voltage P	V
BBB. B	Battery Discharging Current P	A
CCCC. C	Battery Charging Current P	A
DDD. D	Battery Voltage N	V
EEE. E	Battery Discharging Current N	A
FFFF. F	Battery Charging Current N	A
GGG	Battery Capacity	%
HHHH	Battery Remain time	Min

#### 5.7 ^P005QFLG<0x0d>: Setting flag status inquiry

Computer: ^P005QFLG<0x0d>

Case Name:		Date:		Num:	
Case Num:		Version:		PAGE	13/32

UPS: ^D065A0B0C0...Z0a0...e1<CRC H><CRC L><0x0d>

<b>A</b>	Enable/disable all audible alarm (完全静音)
<b>B</b>	Enable/disable battery mode warning mute
<b>C</b>	Enable/disable code start(The gray means not support)
<b>D</b>	Enable/disable battery open status check
<b>E</b>	Enable/disable high efficiency mode (ECO mode)
<b>F</b>	Enable/disable bypass forbidden
<b>G</b>	Enable/disable energy saving
<b>H</b>	Enable/disable short restart 3 times
<b>I</b>	Enable/disable inverter short clear function
<b>J</b>	Enable/disable Output socket1 when the delay release time is over in battery mode .
<b>K</b>	Enable/disable Output socket2 when the delay release time is over in battery mode.
<b>L</b>	Enable/disable Site fault detect
<b>M</b>	Enable/disable hot standby function
<b>N</b>	Enable/disable deep high efficiency mode
<b>O</b>	Enable/disable bypass when UPS turn off. (bps enable/disable)
<b>P</b>	Enable/disable bypass audible warning
<b>Q</b>	Enable/disable Constant Phase Angle function
<b>R</b>	Enable/disable auto-restart
<b>S</b>	Enable/disable battery deep discharge protect
<b>T</b>	Enable/disable battery low protect (if disable, the battery will discharge to 6V)
<b>U</b>	Enable/disable Free run function
<b>V</b>	Enable/disable converter mode
<b>W</b>	Enable/disable limited runtime on battery mode
<b>X</b>	Enable/disable output parallel function in phase angle 0
<b>Y</b>	Enable/disable phase auto adapt
<b>Z</b>	Enable/disable period battery test
<b>a</b>	Enable/disable power walk in delay function

Case Name:		Date:		Num:	
Case Num:		Version:		PAGE	14/32

<b>b</b>	Enable/disable battery test stop by time
<b>c</b>	Enable/disable battery test stop by voltage
<b>d</b>	Enable/disable work without battery
<b>e</b>	Enable/disable frequency auto detection
<b>f</b>	Enable/disable auto battery test function
<b>g</b>	Enable/disable warning mute
<b>h</b>	Enable/disable fault mute
<b>i</b>	Enable/disable all mode mute

### 5.8 ^P004QFS<0x0d>: The last fault code inquiry

Computer: ^P004QFS<0x0d>

UPS: ^D005AA<CRC H><CRC L><0x0d>

Fault 类别	Fault 名称	Fault 代码	Fault 描述
Bus/converter fault	Bus start fail	0x01	规定时间内, bus 电压未达到设定值。
	Bus volt over	0x02	Bus 电压超过上限值。
	Bus volt under	0x03	Bus 电压低于下限值。
	Bus volt unbalance	0x04	正负 Bus 电压之差超出允许范围。
	Bus short	0x05	Bus 电压下降斜率过快。
	PFC over current	0x06	PFC 输入电感电流过大。
	PFC IGBT over current	0x07	PFC IGBT 电流过大
	Input contact fault	0x08	输入接触器故障
Inverter fault	Inverter soft start fail	0x11	规定时间内, inverter 电压未达到设定值。
	Inverter volt high	0x12	Inverter 电压超过上限值。
	Inverter volt low	0x13	Inverter 电压低于下限值。
	L1 inverter short	0x14	L1 inverter 相短路。
	L2 inverter short	0x15	L2 inverter 相短路。
	L3 inverter short	0x16	L3 inverter 相短路。
	L1L2 inverter short	0x17	L1L2 inverter 线短路。
	L2L3 inverter short	0x18	L2L3 inverter 线短路。
	L3L1 inverter short	0x19	L3L1 inverter 线短路。

Case Name:		Date:		Num:	
Case Num:		Version:		PAGE	15/32
	L1 inverter negative power	0x1A	L1 inverter 负功超出允许范围。		
	L2 inverter negative power	0x1B	L2 inverter 负功超出允许范围。		
	L3 inverter negative power	0x1C	L3 inverter 负功超出允许范围。		
Electric link fault	Bat SCR short fault	0x21	Battery scr 短路故障		
	Line SCR short fault	0x22	Line scr 短路故障		
	Inverter relay open fault	0x23	Inverter relay 开路故障		
	Inverter relay/STS short fault	0x24	Inverter relay 或者 STS 短路故障		
	Wiring fault	0x25	输入输出线路反接故障		
	Battery reverse fault	0x26	电池反接故障		
	Battery too high	0x27	电池电压过高, 远超出 over charge 点。		
	Battery too low	0x28	电池电压过低, 远低于 shut down 点。		
	Battery Fuse Open-Circuit Fault	0x29	电池 fuse 开路故障		
	Charger output short	0x2A	Charger 输出端短路		
	BypScrFault	0x2B	Bypass relay 或者 STS 短路故障		
Parallel system fault	CAN communication fault	0x31	CAN bus 通信故障。		
	Host line fault	0x32	主机信号线路故障。		
	Synchronization line fault	0x33	同步信号线路故障。		
	Synchronization pulse line fault	0x34	同步触发信号线路故障,		
	Parallel communication line loss	0x35	并机通信线路丢失故障。		
	Output circuit fault	0x36	输出严重不均流故障。		
Others	Over temperature	0x41	UPS 工作温度过高故障。		
	CPU communication fault	0x42	控制板中 CPU 间通信故障。		
	Overload fault	0x43	过载故障。		
	Fan fault	0x44	风扇模组故障。		

Case Name:		Date:		Num:	
Case Num:		Version:		PAGE	16/32

Charger fault	0x45	充电器故障。
Model fault	0x46	机型设置错误
MCU communication fault	0x47	控制板与通讯板 MCU 通信故障
DSP firmware version incompatible	0x48	控制板软件版本不兼容
IpOPPhaseError	0x49	输入输出相序不兼容
	0x4A	
	0x4B	
	0x4C	
	0x4D	
	0x4E	
	0x4F	
BypScrShort	0x61	旁路 SCR 短路
BypScrOpen	0x62	旁路 SCR 开路
RINVWaveAbnormal	0x63	R 相逆变波形不正常
SINVWaveAbnormal	0x64	S 相逆变波形不正常
TINVWaveAbnormal	0x65	T 相逆变波形不正常
CTSatiation	0x66	CT 饱和
BypassOutputShort(L-N)	0x67	旁路相短路
BypassOutputShort(L-L)	0x68	旁路线短路
InvScrShort	0x69	逆变 SCR 短路
Bus Volt Vary Fault	0x6C	Bus 电压下降斜率过快。
Current Detect Fault	0x6D	电流侦测误差过大
SPS Power Fault	0x6E	SPS 电源错误
BAT Fault	0x6F	电池反接故障
PFC R IGBT Fault	0x71	R 相 PFC IGBT 错误
PFC S IGBT Fault	0x72	R 相 PFC IGBT 错误
PFC T IGBT Fault	0x73	T 相 PFC IGBT 错误



Case Name:		Date:		Num:	
Case Num:		Version:		PAGE	17/32

INV R IGBT Fault	0x74	R 相 INV IGBT 错误
INV S IGBT Fault	0x75	S 相 INV IGBT 错误
INV T IGBT Fault	0x76	T 相 INV IGBT 错误
ISO Over Temp Fault	0x77	变压器温度过高

\*GRAY: Not Support

### 5.9 ^P004QID<0x0d>: UPS serial number inquiry

Computer: ^P004QID<0x0d>

UPS: ^D021AAAAAAAAAAAAAAAAAAAA<CRC H><CRC L><0x0d>

\*Fixed Length 17

### 5.10 ^P004QMD<0x0d>: UPS Mode inquiry

Computer: ^P004QMD<0x0d>

UPS: ^D042AAxxxxxxxx,BBBBBB,CCC,DDD,EEE,FF,GG<CRC H><CRC L><0x0d>

AAxxxxxxxx	unit Name (10 Bytes)	GALLEON2	显示容量信息
BBBBBB	Rating ouput VA (w)		额定功率
CCC	Output Factor	090	means PF 0.9
DDD	Input phase/Output phase	fixed	3/3
EEE	Input Rating voltage		
FFF	Output Rating voltage		
GG	battery piece number		电池节数
HH	voltage per cell	12	固定显示 12

\*This whole length is 10bits, if the model value less than 10 bits, use “#” instead before the UPS model, for example: GALLEON2 3-3 40KL Standard: #GAL2 40KL; GALLEON2 3-3 40KS Standard: ##GAL2 40K,

### 5.11 ^P004QPI<0x0d>: Protocol ID Inquiry

Computer: ^P004QPI<0x0d>

UPS: ^D007PI38<CRC H><CRC L><0x0d>

\*Fixed PI38:Galleon2 3-3 UPS

### 5.12 ^P005QRHL<0x0d> : UPS Range inquiry

Computer: ^P005QRHL<0x0d>

UPS: ^D052AAA, BBB, CC, DD, EEE, FFF, GG, G, HH, H, III, JJJ, KK, K, LL, L <CRCH><CRCL><0

Case Name:		Date:		Num:	
Case Num:		Version:		PAGE	18/32

x0d>

AAA Line Voltage High  
 BBB Line Voltage Low  
 CC. C Line Frequency High  
 DD. D Line Frequency Low  
 EEE Bypass Voltage High  
 FFF Bypass Voltage Low  
 GG. G Bypass Frequency High  
 HH. H Bypass Frequency Low  
 III ECO Voltage High  
 JJJ ECO Voltage Low  
 KK. K ECO Frequency High  
 LL. L ECO Frequency Low

### 5.13 ^P004QRI<0x0d>: UPS Rating Information inquiry

Computer: ^P004QRI<0x0d>

UPS: ^D022AAA.A,CCC.C,DDD,EE.E<CRC H><CRC L><0x0d>

AAA. A Rating output voltage  
 CCC. C Rating battery voltage  
 DDD Reserved  
 EE. E Rating output frequency

### 5.14 ^P005QTPR<0x0d>: The temperature inquiry

Computer: ^P005QTPR<0x0d>

UPS: ^D018AAA,BBB,CCC,DDD<CRC H><CRC L><0x0d>

AAA temperature 1  
 BBB temperature 2  
 CCC Temperature 3  
 DDD Max temperature

### 5.15 ^P005QVFW<0x0d>::DSP and CPU Firmware version inquiry

Computer: ^P005QVFW<0x0d>

UPS: ^D024AAAA,BB.CC,DDDD,EE.FF,GGGG,HH.II<CRC H><CRC L><0x0d>

AAAA DSP1 firmware number

Case Name:		Date:		Num:	
Case Num:		Version:		PAGE	19/32

BB DSP1 firmware version  
 CC DSP1 firmware extra version  
 DDDD MCU firmware number  
 EE MCU firmware version  
 FF MCU firmware extra version

### 5.16 ^P004QWS<0x0D>: Warning Status Inquiry

Computer: ^P004QWS<0x0D>

UPS: ^D075a0a1...a71<CRC H><CRC L><0x0d>

bit	code		note
a0	1	Battery open	电池未接报警。
a1	2	IP N loss	输入 N 线丢失报警。
a2	3	IP site fail	输入零火线接反报警。
a3	4	Line phase error	三相输入时，市电 L1/L2/L3 相序错误。
a4	5	Bypass phase error	三相输入时，旁路 L1/L2/L3 相序错误。
a5	6	Bypass frequency unstable	旁路输入频率变化过快，超出 UPS 锁相能力。
a6	7	Battery over charge	电池过充报警。
a7	8	Battery low	电池低压报警。
a8	9	Overload warning	过载报警。
a9	0A	Fan lock warning	风扇模组堵转报警。（GALLEON2 加入）
a10	0B	EPO active	EPO 开关生效。
a11	0C	Turn on abnormal	系统不允许开机。
a12	0D	Over temperature	过温报警。
a13	0E	CHGFail	CHG 故障（GALLEON2 更改）
a14	0F	Remote shut down	远程自动关机报警。
a15	10	L1 IP fuse fail	L1 输入保险开路报警。
a16	11	L2 IP fuse fail	L2 输入保险开路报警。
a17	12	L3 IP fuse fail	L3 输入保险开路报警。
a18	13	L1 PFC positive error	L1 正边 PFC 工作异常，连续 48 个 count PWM 输出始终为满偏。

Case Name:		Date:		Num:	
Case Num:		Version:		PAGE	20/32

a19	14	L1 PFC negative error	L1 负边 PFC 工作异常, 连续 48 个 count PWM 输出始终为满偏。
a20	15	L2 PFC positive error	L2 正边 PFC 工作异常, 连续 48 个 count PWM 输出始终为满偏。
a21	16	L2 PFC negative error	L2 负边 PFC 工作异常, 连续 48 个 count PWM 输出始终为满偏。
a22	17	L3 PFC positive error	L3 正边 PFC 工作异常, 连续 48 个 count PWM 输出始终为满偏。
a23	18	L3 PFC negative error	L3 负边 PFC 工作异常, 连续 48 个 count PWM 输出始终为满偏。
a24	19	CAN communication error	CAN bus 通信报警。
a25	1A	Synchronization line error	同步信号线路报警。
a26	1B	Synchronization pulse error	同步触发信号线路报警。
a27	1C	Host line error	主机信号线路报警。
a28	1D	Male connection error	并机通信线公端连接脱落报警。
a29	1E	Female connection error	并机通信线母端连接脱落报警。
a30	1F	Parallel line connection error	并机通信线脱落报警
a31	20	Battery connect different	并机系统各模块电池连接不一致。
a32	21	Line connect different	并机系统各模块市电连接不一致。(GALLEON2 加入)
a33	22	Bypass connect different	并机系统各模块旁路连接不一致。(GALLEON2 加入)
a34	23	Mode type different	并机系统中各 UPS 机种类型不一致。
a35	24	Parallel inverter voltage setting different	并机系统逆变电压设置不一致。
a36	25	Parallel output frequency setting different	并机系统输出频率设置不一致。
a37	26	Battery cell over charge	电池单体过充电
a38	27	Parallel output parallel setting different	并机系统输出并联设置不一致。
a39	28	Parallel output phase setting different	并机系统输出相角设置不一致。
a40	29	Parallel Bypass Forbidden setting different	并机系统旁路禁止标志位设置不一致。
a41	2A	Parallel Converter Enable	并机系统 CVCF 标志位设置不一致。

Case Name:		Date:		Num:	
Case Num:		Version:		PAGE	21/32

		setting different	
a42	2B	Parallel Bypass Freq High loss setting different	并机系统旁路频率丢失点上限设置不一致。
a43	2C	Parallel Bypass Freq Low loss setting different	并机系统旁路频率丢失点下限设置不一致。
a44	2D	Parallel Bypass Volt High loss setting different	并机系统旁路电压丢失点上限设置不一致。
a45	2E	Parallel Bypass Volt Low Loss setting different	并机系统旁路电压丢失点下限设置不一致。
a46	2F	Parallel Line Freq High Loss setting different	并机系统市电频率丢失点上限设置不一致。
a47	30	Parallel Line Freq Low Loss setting different	并机系统市电频率丢失点下限设置不一致。
a48	31	Parallel Line Volt High Loss setting different	并机系统市电电压丢失点上限设置不一致。
a49	32	Parallel Line Volt Low Loss setting different	并机系统市电电压丢失点下限设置不一致。
a50	33	Locked in bypass after overload 3 times in 30min	30 分钟内过载三次锁在旁路告警。
a51	34	Warning for three-phase AC input current unbalance	PFC 输入电流不平衡告警。
a52	35	Battery Phase loss	电池相序丢失
a53	36	Inverter current unbalance	逆变并板不均流告警。（GALLEON2 加入）
a54	37	P1 cut off pre-alarm	P1 切断预警
a55	38	Warning for Battery replace	电池需要更换告警（GALLEON2 不支持）
a56	39	Warning for input phase error	输入相角不正常告警
a57	3A	Cover of maintain switch is open	维护旁路开路报警
a58	3B	Phase Auto Adapt Failed	相位自动侦测失败
a59	3C	Utility extremely unbalanced	市电电压极度不平衡（GALLEON2 加入）
a60	3D	Bypass unstable	旁路状态不稳定（GALLEON2 加入）
a62		Parallel protect warning	并机保护告警。提示机器上次运行时出现了并机通讯线丢失故障。
a63		Discharger overly	电池过放电告警,需要进行保护

Case Name:		Date:		Num:	
Case Num:		Version:		PAGE	22/32

a64		Battery too high	电池电压远高于 overcharge 点
a65		Battery too low	电池电压过低
a66	3E	Battery Volt High	电池电压过高 (GALLEON2 对应告警码不一样)
a67	3F	Battery Volt Unbalance	电池电压不平衡 (GALLEON2 对应告警码不一样)
a68	40	CHG Short	CHG 短路 (GALLEON2 对应告警码不一样)

\*GRAY:Not Support Now

### 5.17 ^P006QTYPE<0x0D>:INPUT TYPE INQUIRY

Computer: ^P006QTYPE<0x0D>

UPS: ^D012A.....<CRC H><CRC L><0x0d>

A            Intype    0: line        /    1:Generator  
 B                        0: single input/    1: dual input  
 C                        0: HV         /    1: LV  
 D            -  
 E            -  
 FFF         ----

\*New Add

## 6 Set Command

### 6.1 ^S005BOFF<0x0d>: Silence buzzer beep

Computer: ^S005BOFF<0x0d>

UPS: ^D006ACK<CRC H><CRC L><0x0d>

if UPS accepts this command, otherwise, responds ^D006NAK<CRC H><CRC L><0x0d>

Means: The buzzer beep silence .

### 6.2 ^S004BON<0x0d>: buzzer beep open

Computer: ^S004BON<0x0d>

UPS: ^D006ACK<CRC H><CRC L><0x0d>

if UPS accepts this command, otherwise, responds ^D006NAK<CRC H><CRC L><0x0d>

Means: The buzzer beep open

### 6.3 ^S005CFTD<0x0d>: default calibration factor

Computer: ^S005CFTD<0x0d>

Case Name:		Date:		Num:	
Case Num:		Version:		PAGE	23/32

UPS: ^D006ACK<CRC H><CRC L><0x0d>

if UPS accepts this command, otherwise, responds ^D006NAK<CRC H><CRC L><0x0d>

Means: Restore calibration factor

\*take effect when UPS turn on next time

#### 6.4 ^S009CHMC04.0<0x0d>: set charging current

Computer: ^S009CHMC04.0<0x0d>

UPS: ^D006ACK<CRC H><CRC L><0x0d>

if UPS accepts this command, otherwise, responds ^D006NAK<CRC H><CRC L><0x0d>

Means: set the max charging current, unit is A

#### 6.5 ^S003CS<0x0d>:cancel shutdown and restore

Computer: ^S003CS<0x0d>

UPS: ^D006ACK<CRC H><CRC L><0x0d>

if UPS accepts this command, otherwise, responds ^D006NAK<CRC H><CRC L><0x0d>

Means: Cancel the S<n><cr> and S<n>R<m><cr> **and SON** command.

If UPS is in waiting shutdown state, the shut down command is cancelled.

If UPS is in waiting restore state, the UPS output is turned on, but UPS must be hold off at least 10 seconds. (If utility is present)

#### 6.6 ^S003CT<0x0d>: cancel battery test

Computer: ^S003CT<0x0d>

UPS: ^D006ACK<CRC H><CRC L><0x0d>

if UPS accepts this command, otherwise, responds ^D006NAK<CRC H><CRC L><0x0d>

Means: Cancel all test activity and connect the utility to output immediately.

#### 6.7 ^S009PHFH52.0<0x0d>:set eco freq high loss point

Computer: ^S009PHFH52.0<0x0d>

UPS: ^D006ACK<CRC H><CRC L><0x0d>

if UPS accepts this command, otherwise, responds ^D006NAK<CRC H><CRC L><0x0d>

Means: Set ECO freq high loss point,unit is Hz;The max freq point is 52.0Hz

#### 6.8 ^S009PHFL48.0<0x0d>:set eco freq low loss point

Computer: ^S009PHFL48.0<0x0d>

UPS: ^D006ACK<CRC H><CRC L><0x0d>

Case Name:		Date:		Num:	
Case Num:		Version:		PAGE	24/32

if UPS accepts this command, otherwise, responds ^D006NAK<CRC H><CRC L><0x0d>  
Means: Set ECO freq low loss point,unit is Hz;The min freq point is 48.0Hz

### 6.9 ^S008PHVH240<0x0d>:set eco voltage high loss

Computer: ^S008PHVH240

UPS: ^D006ACK<CRC H><CRC L><0x0d>

if UPS accepts this command, otherwise, responds ^D006NAK<CRC H><CRC L><0x0d>

Means: Set ECO voltage high loss point,unit is V;The max freq point is (op volt+11V)

### 6.10 ^S008PHVL200<0x0d>:seteco voltage Low loss

Computer: ^S008PHVL200<0x0d>

UPS: ^D006ACK<CRC H><CRC L><0x0d>

if UPS accepts this command, otherwise, responds ^D006NAK<CRC H><CRC L><0x0d>

Means: Set ECO voltage loss point,unit is V;The min voltage point is (op volt-11V)

### 6.11 ^S005PFTD<0x0d>:default parameter Factor

Computer: ^S005PFTD<0x0d>

UPS: ^D006ACK<CRC H><CRC L><0x0d>

if UPS accepts this command, otherwise, responds ^D006NAK<CRC H><CRC L><0x0d>

Means: Set the bypass voltage and freq to default

Set the ECO voltage and freq to default

Set the Control Flag to default

### 6.12 ^S009PSFH52.0<0x0d>:set bypass freq high loss point

Computer: ^S009PSFH52.0<0x0d>

UPS: ^D006ACK<CRC H><CRC L><0x0d>

if UPS accepts this command, otherwise, responds ^D006NAK<CRC H><CRC L><0x0d>

Means: set bypass freq high loss point ,unit is Hz; The high freq range is 51~54Hz or 61~64Hz

### 6.13 ^S009PSFL48.0<0x0d>:set bypass freq low loss point

Computer: ^S009PSFL48.0<0x0d>

UPS: ^D006ACK<CRC H><CRC L><0x0d>

if UPS accepts this command, otherwise, responds ^D006NAK<CRC H><CRC L><0x0d>

Means: set bypass freq low loss point ,unit is Hz; The low freq range is 51~54Hz or 61~64Hz



Case Name:		Date:		Num:	
Case Num:		Version:		PAGE	25/32

#### 6.14 ^S010PSVH240.0<0x0d>:set bypass voltage high loss point

Computer: ^S010PSVH240.0<0x0d>

UPS: ^D006ACK<CRC H><CRC L><0x0d>

if UPS accepts this command, otherwise, responds ^D006NAK<CRC H><CRC L><0x0d>

Means: set bypass voltage high loss point, unit isV; The high voltage range is 231~276V

#### 6.15 ^S010PSVL200.0<0x0d>:set bypass voltage low loss point

Computer: ^S010PSVL200.0<0x0d>

UPS: ^D006ACK<CRC H><CRC L><0x0d>

if UPS accepts this command, otherwise, responds ^D006NAK<CRC H><CRC L><0x0d>

Means: set bypass voltage high loss point, unit is V; The high voltage range 176~209V

#### 6.16 ^S005REEP<0x0d>:restore eeprom date

Computer: ^S005REEP<0x0d>

UPS: ^D006ACK<CRC H><CRC L><0x0d>

if UPS accepts this command, otherwise, responds ^D006NAK<CRC H><CRC L><0x0d>

Means: Restore eeprom date to default

\*take effect when UPS turn on next time

#### 6.17 ^S009SBHV15.0<0x0d>:set the battery high warning voltage

Computer: ^S009SBHV15.0<0x0d>

UPS: ^D006ACK<CRC H><CRC L><0x0d>

if UPS accepts this command, otherwise, responds ^D006NAK<CRC H><CRC L><0x0d>

Means: Set the battery high warning voltage, unit is V/pcs; The voltage range is 14.0~15.0V

#### 6.18 ^S009SBLV11.4<0x0d>:set the battery low warning voltage

Computer: ^S009SBLV11.4<0x0d>

UPS: ^D006ACK<CRC H><CRC L><0x0d>

if UPS accepts this command, otherwise, responds ^D006NAK<CRC H><CRC L><0x0d>

Means: set the battery low warning voltage, unit is V/pcs; The voltage range is (Under volt Point+0.1V)~( Under volt Point +2V)

Case Name:		Date:		Num:	
Case Num:		Version:		PAGE	26/32

### 6.19 ^S009SBSV10.5<0x0d>:set the battery under(shutdown) voltage

Computer: ^S009SBSV10.5<0x0d>

UPS: ^D006ACK<CRC H><CRC L><0x0d>

if UPS accepts this command, otherwise, responds ^D006NAK<CRC H><CRC L><0x0d>

Means: Set the battery under(shutdown) voltage, unit is V/pcs; The voltage range is 10.5~12.0V

### 6.20 ^S008SOPV220<0x0d>:set output voltage

Computer: ^S008SOPV220<0x0d>

UPS: ^D006ACK<CRC H><CRC L><0x0d>

if UPS accepts this command, otherwise, responds ^D006NAK<CRC H><CRC L><0x0d>

Means: set output voltage,unit is V;The volt point is 208\220\230\240V

### 6.21 ^S005SN.6<0x0d>:set shut down time in nn minute

Computer: ^S005SN.6<0x0d>

UPS: ^D006ACK<CRC H><CRC L><0x0d>

if UPS accepts this command, otherwise, responds ^D006NAK<CRC H><CRC L><0x0d>

Means: Set shut down time in nn minute

### 6.22 ^S005SOFF<0x0d>:turn off the UPS

Computer: ^S005SOFF<0x0d>

UPS: ^D006ACK<CRC H><CRC L><0x0d>

if UPS accepts this command, otherwise, responds ^D006NAK<CRC H><CRC L><0x0d>

Means: turn off the UPS

### 6.23 ^S004SON<0x0d>:turn on the UPS

Computer: ^S004SON<0x0d>

UPS: ^D006ACK<CRC H><CRC L><0x0d>

if UPS accepts this command, otherwise, responds ^D006NAK<CRC H><CRC L><0x0d>

Means: turn on the UPS

### 6.24 ^S009SOPF60.0<0x0d>:set the output frequency

Computer: ^S009SOPF60.0<0x0d>

UPS: ^D006ACK<CRC H><CRC L><0x0d>

Case Name:		Date:		Num:	
Case Num:		Version:		PAGE	27/32

if UPS accepts this command, otherwise, responds ^D006NAK<CRC H><CRC L><0x0d>  
Means: Set UPS output nominal frequency to 50Hz or 60Hz. (Only in bypass mode)

### 6.25 ^S005SPDA<0x0d>:disable control flag

Computer: ^S005SPDA<0x0d>

UPS: ^D006ACK<CRC H><CRC L><0x0d>

if UPS accepts this command, otherwise, responds ^D006NAK<CRC H><CRC L><0x0d>

Means: Disable control flag

No	Control setting
A	Enable/disable all audible alarm (完全静音)
B	Enable/disable battery mode warning mute
E	Enable/disable high efficiency mode (ECO mode)
F	Enable/disable bypass forbidden
I	Enable/disable inverter short clear function
M	Enable/disable hot standby function
O	Enable/disable bypass when UPS turn off. (bps enable/disable)
P	Enable/disable bypass audible warning
R	Enable/disable auto-restart
S	Enable/disable battery deep discharge protect
V	Enable/disable converter mode
i	Enable/disable all mode mute

\*GRAY: Not support now

### 6.26 ^S005SPEA<0x0d>:enable control flag

Computer: ^S005SPEA<0x0d>

UPS: ^D006ACK<CRC H><CRC L><0x0d>

if UPS accepts this command, otherwise, responds ^D006NAK<CRC H><CRC L><0x0d>

Means: Enable control flag

### 6.27 ^S007SR0010<0x0d>:restart in nnnn minute

Computer: ^S007SR0010<0x0d>

UPS: ^D006ACK<CRC H><CRC L><0x0d>

Case Name:		Date:		Num:	
Case Num:		Version:		PAGE	28/32

if UPS accepts this command, otherwise, responds ^D006NAK<CRC H><CRC L><0x0d>  
Means: Set restart time in nnnn minute

### 6.28 ^S022STID0123456789abcdef<0x0d>:set ups serial number

Computer: ^S022STID0123456789abcdef<0x0d>

UPS: ^D006ACK<CRC H><CRC L><0x0d>

if UPS accepts this command, otherwise, responds ^D006NAK<CRC H><CRC L><0x0d>

Means: Set the serial number of UPS

\*This whole length is 17bits, if the value less than 17bits, use "0" to instead

### 6.29 ^S004T10<0x0d>:do battery test for 10 second

Computer: ^S004T10<0x0d>

UPS: ^D006ACK<CRC H><CRC L><0x0d>

if UPS accepts this command, otherwise, responds ^D006NAK<CRC H><CRC L><0x0d>

Means: do battery test for 10 second

### 6.30 ^S003TL<0x0d>:do battery test until battery low

Computer: ^S003TL<0x0d>

UPS: ^D006ACK<CRC H><CRC L><0x0d>

if UPS accepts this command, otherwise, responds ^D006NAK<CRC H><CRC L><0x0d>

Means: do battery test until battery low

### 6.31 ^S005TN.8<0x0d>:do battery test for nn minute

Computer: ^S005TN.8<0x0d>

UPS: ^D006ACK<CRC H><CRC L><0x0d>

if UPS accepts this command, otherwise, responds ^D006NAK<CRC H><CRC L><0x0d>

Means: do battery test for nn minute

### 6.32 ^S009SINTYPE<n><0x0d>:set input Type Line or generator

Computer: ^S009SINTYPE<n><0x0d>

UPS: ^D006ACK<CRC H><CRC L><0x0d>

if UPS accepts this command, otherwise, responds ^D006NAK<CRC H><CRC L><0x0d>

Means: set input Type Line or generator

\*'0':normal line input;

Case Name:		Date:		Num:	
Case Num:		Version:		PAGE	29/32

'1': generator input

## 7 Calibration Command

### 7.1 ^C008RLV+007<0x0d>: calibration R line voltage

Computer: ^C008RLV+007<0x0d>

UPS: ^D006ACK<CRC H><CRC L><0x0d>

if UPS accepts this command, otherwise, responds ^D006NAK<CRC H><CRC L><0x0d>

Means: Calibration R line voltage percent value; The range of the value is 0~10%

### 7.2 ^C008SLV+007<0x0d>: calibration S line voltage

Computer: ^C008SLV+007<0x0d>

UPS: ^D006ACK<CRC H><CRC L><0x0d>

if UPS accepts this command, otherwise, responds ^D006NAK<CRC H><CRC L><0x0d>

Means: Calibration S line voltage percent value; The range of the value is 0~10%

### 7.3 ^C008TLV+007<0x0d>: calibration T line voltage

Computer: ^C008TLV+007<0x0d>

UPS: ^D006ACK<CRC H><CRC L><0x0d>

if UPS accepts this command, otherwise, responds ^D006NAK<CRC H><CRC L><0x0d>

Means: Calibration T line voltage percent value; The range of the value is 0~10%

### 7.4 ^C008ROV+007<0x0d>: calibration R output voltage

Computer: ^C008ROV+007<0x0d>

UPS: ^D006ACK<CRC H><CRC L><0x0d>

if UPS accepts this command, otherwise, responds ^D006NAK<CRC H><CRC L><0x0d>

Means: Calibration R Output voltage percent value; The range of the value is 0~10%.

### 7.5 ^C008SOV+007<0x0d>: calibration S output voltage

Computer: ^C008SOV+007<0x0d>

UPS: ^D006ACK<CRC H><CRC L><0x0d>

if UPS accepts this command, otherwise, responds ^D006NAK<CRC H><CRC L><0x0d>

Means: Calibration S Output voltage percent value; The range of the value is 0~10%.

Case Name:		Date:		Num:	
Case Num:		Version:		PAGE	30/32

### 7.6 ^C008TOV+007<0x0d>: calibration T output voltage

Computer: ^C008TOV+007<0x0d>

UPS: ^D006ACK<CRC H><CRC L><0x0d>

if UPS accepts this command, otherwise, responds ^D006NAK<CRC H><CRC L><0x0d>

Means: Calibration T Output voltage percent value; The range of the value is 0~10%.

### 7.7 ^C008ROC+007<0x0d>: calibration R output current

Computer: ^C008ROC+007<0x0d>

UPS: ^D006ACK<CRC H><CRC L><0x0d>

if UPS accepts this command, otherwise, responds ^D006NAK<CRC H><CRC L><0x0d>

Means: Calibration R Output current percent value; The range of the value is 0~12.5%.

### 7.8 ^C008SOC+007<0x0d>: calibration S output current

Computer: ^C008SOC+007<0x0d>

UPS: ^D006ACK<CRC H><CRC L><0x0d>

if UPS accepts this command, otherwise, responds ^D006NAK<CRC H><CRC L><0x0d>

Means: Calibration S Output current percent value; The range of the value is 0~12.5%.

### 7.9 ^C008TOC+007<0x0d>: calibration T output current

Computer: ^C008TOC+007<0x0d>

UPS: ^D006ACK<CRC H><CRC L><0x0d>

if UPS accepts this command, otherwise, responds ^D006NAK<CRC H><CRC L><0x0d>

Means: Calibration T Output current percent value; The range of the value is 0~12.5%.

### 7.10 ^C009RIVV+007<0x0d>:calibration R inverter voltage

Computer: ^C009RIVV+007<0x0d>

UPS: ^D006ACK<CRC H><CRC L><0x0d>

if UPS accepts this command, otherwise, responds ^D006NAK<CRC H><CRC L><0x0d>

Means: Calibration R inverter voltage percent value; The range of the value is 0~10%.

### 7.11 ^C009SIVV+007<0x0d>:calibration S inverter voltage

Computer: ^C009SIVV+007<0x0d>

UPS: ^D006ACK<CRC H><CRC L><0x0d>

Case Name:		Date:		Num:	
Case Num:		Version:		PAGE	31/32

if UPS accepts this command, otherwise, responds ^D006NAK<CRC H><CRC L><0x0d>  
Means: Calibration S inverter voltage percent value; The range of the value is 0~10%.

#### 7.12 ^C009TIVV+007<0x0d>:calibration T inverter voltage

Computer: ^C009TIVV+007<0x0d>

UPS: ^D006ACK<CRC H><CRC L><0x0d>

if UPS accepts this command, otherwise, responds ^D006NAK<CRC H><CRC L><0x0d>

Means: Calibration T inverter voltage percent value; The range of the value is 0~10%.

#### 7.13 ^C009RBYV+007<0x0d>: calibration R bypass voltage

Computer: ^C009RBYV+007<0x0d>

UPS: ^D006ACK<CRC H><CRC L><0x0d>

if UPS accepts this command, otherwise, responds ^D006NAK<CRC H><CRC L><0x0d>

Means: Calibration R Bypass voltage percent value; The range of the value is 0~10%.

#### 7.14 ^C009SBYV+007<0x0d>: calibration S bypass voltage

Computer: ^C009SBYV+007<0x0d>

UPS: ^D006ACK<CRC H><CRC L><0x0d>

if UPS accepts this command, otherwise, responds ^D006NAK<CRC H><CRC L><0x0d>

Means: Calibration S Bypass voltage percent value; The range of the value is 0~10%.

#### 7.15 ^C009TBYV+007<0x0d>: calibration T bypass voltage

Computer: ^C009TBYV+007<0x0d>

UPS: ^D006ACK<CRC H><CRC L><0x0d>

if UPS accepts this command, otherwise, responds ^D006NAK<CRC H><CRC L><0x0d>

Means: Calibration T Bypass voltage percent value; The range of the value is 0~10%.

#### 7.16 ^C010BUSPV+007<0x0d>:calibration positive bus voltage

Computer: ^C010BUSPV+007<0x0d>

UPS: ^D006ACK<CRC H><CRC L><0x0d>

if UPS accepts this command, otherwise, responds ^D006NAK<CRC H><CRC L><0x0d>

Means: Calibration positive BUS voltage percent value; The range of the value is 0~10%.

Case Name:		Date:		Num:	
Case Num:		Version:		PAGE	32/32

### 7.17 ^C010BUSNV+007<0x0d>:calibration negative bus voltage

Computer: ^C010BUSPN+007<0x0d>

UPS: ^D006ACK<CRC H><CRC L><0x0d>

if UPS accepts this command, otherwise, responds ^D006NAK<CRC H><CRC L><0x0d>

Means: Calibration negative BUS voltage percent value; The range of the value is 0~10%.

### 7.18 ^C010BATPV+007<0x0d>:calibration positive battery voltage

Computer: ^C010BATPV+007<0x0d>

UPS: ^D006ACK<CRC H><CRC L><0x0d>

if UPS accepts this command, otherwise, responds ^D006NAK<CRC H><CRC L><0x0d>

Means: Calibration positive battery voltage percent value; The range of the value is 0~10%.

### 7.19 ^C010BATNV+007<0x0d>:calibration negative battery voltage

Computer: ^C010BATNV+007<0x0d>

UPS: ^D006ACK<CRC H><CRC L><0x0d>

if UPS accepts this command, otherwise, responds ^D006NAK<CRC H><CRC L><0x0d>

Means: Calibration negative battery voltage percent value; The range of the value is 0~10%.